

Option Standard

1. Cyan
2. Magenta
3. Yellow
4. Uniform Field Lens
5. Colour Wheel
6. Stopper/Strobe
7. Dimmer
8. Dimmer Fine
9. Iris
10. Static Gobo Change
11. Rotating Gobo Change
12. Gobo Rotation
13. Gobo Fine
14. Prism Insertion
15. Prism Rotation
16. Frost
17. Focus
18. Zoom
19. Pan
20. Pan Fine
21. Tilt
22. Tilt Fine
23. Function
24. Reset
25. Lamp Control (with Option "Lamp DMX" ON)

OPTION VECTOR

1. Cyan
2. Magenta
3. Yellow
4. Uniform Field Lens
5. Colour Wheel 6. Stopper/Strobe
7. Dimmer
8. Dimmer Fine
9. Iris
10. Static Gobo Change
11. Rotating Gobo Change
12. Gobo Rotation
13. Gobo Fine
14. Prism Insertion
15. Prism Rotation
16. Frost
17. Focus
18. Zoom
19. Pan
20. Pan Fine
21. Tilt
22. Tilt Fine
23. Function
24. Reset
25. Lamp Control (with option "Lamp DMX" ON)
26. Pan – Tilt Time
27. Colour Time
28. Beam Time
29. Gobo Time