

Mode 1 - 6 Channel 8 - Bit Pan/Tilt

- 1.Strobe
- 2.Colour
- 3.Gobo
- 4.Gobo Rotate
- 5.Pan
- 6.Tilt

Mode 2 - 8 Channel 16 - Bit Pan/Tilt

- 1.Strobe
- 2.Colour
- 3.Gobo
- 4.Gobo Rotate
- 5.Pan
- 6.Fine Pan
- 7.Tilt
- 8.Fine Tilt

Mode 3 - 8 Channel 8 - Bit Pan/Tilt

- 1.Strobe
- 2.Colour
- 3.Gobo
- 4.Gobo Rotate
- 5.Pan
- 6.Tilt
- 7.Speed
- 8.Control/Macro

Mode 4 -10 Channel 16 - Bit Pan/Tilt

- 1.Strobe
- 2.Colour
- 3.Gobo
- 4.Gobo Rotate
- 5.Pan
- 6.Fine Pan
- 7.Tilt
- 8.Fine Tilt
- 9.Speed
- 10.Control/Macro