

DMX Protocol

1. Pan High
2. Pan Low
3. Tilt High
4. Tilt Low
5. Intensity High
6. Intensity Low
7. Shutter / Strobe
8. Colour Wheel
9. Cyan Colour Flag High
10. Cyan Colour Flag Low
11. Magenta Colour Flag High
12. Magenta Colour Flag Low
13. Yellow Colour Flag High
14. Yellow Colour Flag Low
15. CTO Colour Flag
16. Zoom High
17. Zoom Low
18. Focus High
19. Focus Low
20. Gobo Wheel 1
21. Gobo Wheel 1 Index / Rotation High
22. Gobo Wheel 1 Index Rotation Low
23. Gobo Wheel 2 (Fixed Gobo Wheel)
24. Prism
25. Prism Index/Rotation High
26. Prism Index/Rotation Low
27. Frost
28. Iris
29. Blade 1 A Insert High
30. Blade 1 A Insert Low
31. Blade 1 B Insert High
32. Blade 1 B Insert Low
33. Blade 2 A Insert High

34. Blade 2 A insert Low
35. Blade 2 B Insert High
36. Blade 2 B Insert Low
37. Blade 3 A Insert High
38. Blade 3 A insert Low
39. Blade 3 B Insert High
40. Blade 3 B Insert Low
41. Blade 4 A Insert High
42. Blade 4 A insert Low
43. Blade 4 B Insert High
44. Blade 4 B Insert Low
45. Blade Gate Rotation High
46. Blade Gate Rotation Low
47. Blade Macro effects
48. Blade speed / timing
49. Movement Speed / Timing
50. Auto Focus
51. CMY Speed / Timing
52. Dimmer Mode
53. Control Channel